

Instructions to run a Test Job on Maxsys

These instructions were written for Maxsys version 2.0

- 1) If the Test Job to be run contains a smart card application, ensure that the smart card application is registered with Maxsys. Registering a job is done within the “Smart Card Management” part of Maxsys Administrator. See the online help topic “About Application Management” for more details.
- 2) In Windows, click on Maxsys Production icon to start up Production
- 3) Ensure the Machine status is “Idled. This status is found in the “Machine” button located along top of screen. You cannot run any kind of job unless the machine is in the “Idled” state.
- 4) Click on {Production} tab (located in upper, left corner of Production screen). A graphic depiction of the machine will appear.
- 5) Click on [Start Test Job] button which is located underneath the {All Jobs} tab, slightly to right and below the {Production} tab. A dialog will open up displaying those Test Jobs available to run.
- 6) Select a job and click the [Run Test] button. The machine will start to produce cards.